




IMPORTANT:


When printing this document, the “Fit to page” option must be UNCHECKED or the “Page Scaling” option must be set to NONE depending on your printers options. If this option is set incorrectly, the prints will not work correctly as center point guides because they will not print at actual size.




OC07201




OC07202




OC07203




OC07204




OC07205




OC07206




OC07207



OC07208




OC07209




OC07210




OC07211



OC07212



OC07213



OC07214

